


Chroma-Q Ethernet Uploader

The Chroma-Q Ethernet Uploader application is designed to upload firmware to Chroma-Q Ethernet-enabled fixtures, such as the Inspire PoE.

To use the software:


1. Unzip and install it on a Windows 10/11 PC.
2. Connect as many fixtures as your network allows.
3. Ensure no other devices are transmitting on the network, such as lighting consoles or software like DMXWorkshop or Luminex monitoring software.
4. Select the appropriate NIC for transmission (the default range for fixtures is 2.x.x.x).
5. Browse for and select the .alf file included in the zip.

Note: If the checkbox remains unchecked, you will be able to see which fixtures are detected.



Apply to have the firmware sent.

Force All to force an update even if fixtures have the same firmware version.



Fixtures will be sequentially updated.

They will blink blue while receiving packets and turn green once the update is completed correctly.

If some fixtures fail to update, they should reboot, and a new update can be sent again.

Uncheck "Force Update" to send the update only to those that did not receive it in the first attempt.