# **Quick Start Guide**

## Chroma-Q<sup>®</sup> Color Span 2™





For a full product manual please visit www.chroma-q.com Part Number: CHSP2[XXXXX] Model: 633-XXXX

#### 1. Overview

The Chroma-Q Color Span 2<sup>™</sup> is a configurable low profile, ultra bright LED indoor cove lighting and wall wash system for wide ranging applications.

The Color Span 2 <sup>™</sup> fixture comes in lengths of 400mm / 16" with 16 LEDs, 800mm / 32" with 32 LEDs, and 1200mm / 48" with 48 LEDs. The Color Span 2 <sup>™</sup> fixtures of various lengths can be combined and connected via the RJ45 in/out connectors for power and data. The total lengths of the combined fixtures must match the corresponding power supply output.

## 2. Safety



- This product is for professional use only. It is NOT intended for domestic or outdoor use.
- 2. The bright flash of light during power-up and continuous strobe effect may cause epileptic seizure.

## 3. Chroma-Q<sup>®</sup> Color Span 2<sup>™</sup> Power Supply Units

The Color Span 2<sup>TM</sup> PS02, PS06 and PS18 are power supply units which can be remotely controlled via ANSI E1.11 USITT DMX 512-A (XLR 5-pin) and available with outputs via RJ45 connection.

Color Span 2<sup>™</sup> PS02 is a power supply with 2 outputs which can be configured for up to 2 full-size (1200mm/48") 48 LEDs Color Span 2<sup>™</sup> fixture units, or 2 (800mm/32") 32 LEDs Color Span 2<sup>™</sup> fixtures, or 2 (400mm/16") 16 LEDs Color Span 2<sup>™</sup> fixtures, or combined (daisy-chained) to match each output.

Color Span 2<sup>™</sup> PS06 is a power supply with 6 outputs which can be configured for up to 6 full-size (1200mm/48") 48 LEDs Color Span 2<sup>™</sup> fixture units, or 6 (800mm/32") 32 LEDs Color Span 2<sup>™</sup> fixtures, or 6 (400mm/16") 16 LEDs Color Span 2<sup>™</sup> fixtures, or combined (daisy-chained) to match each output.

Color Span 2<sup>™</sup> PS18 is a power supply with 18 outputs which can be configured for up to 18 full-size (1200mm/48") 48 LEDs Color Span 2<sup>™</sup> fixtures, or 18 (800mm/32") 32 LEDs Color Span 2<sup>™</sup> fixtures, or 18 (400mm/16") 16 LEDs Color Span 2<sup>™</sup> fixtures, or combined (daisy-chained) to match each output.

**Caution:** The total lengths of combined Color Span 2 <sup>TM</sup> fixtures must not be less or more than the power output of the power supply unit. The power supply unit will be damaged if the total length of combined fixtures is not matched to the corresponding output used.

A POWER TERMINATOR must be connected to the last fixture in the combined (daisy-chained) configuration series.

#### **Output and cabling Configuration**

The PS02, PS06 and PS18 have 3 output configurations for up to 6 fixture configurations. Each RJ45 output connector of the Color Span 2<sup>TM</sup> PS02, PS06 and PS18 are color coded to indicate the appropriate number and/or combination of Color Span 2<sup>TM</sup> fixture units.

Output Connector Color	Number of LEDs in the	Fixture Length
Code	fixture	
BROWN	16	400mm / 16"
ORANGE	32	800mm / 32"
YELLOW	48	1200mm / 48"

**Output Configuration:** 

PSU	Color Code	Fixture Configuration/Combination		
	Yellow	2/6/18 outputs x (48 LEDs fixture) or		
PS02/ PS06/ PS18		2/6/18 outputs x (32 LEDs + 16 LEDs fixture) or		
		2/6/18 outputs x (16 LEDs + 16 LEDs + 16 LEDs fixture)		
	Orange	2/6/18 outputs x (32 LEDs fixture) or		
		2/6/18 outputs x (16 LEDs + 16 LEDs fixture)		
	Brown	2/6/18 outputs x (16 LEDs fixture)		

Note: Damage may occur to the fixture if the size is not matched to the coded outputs.

### 4. Control

Control Menu

The Color Span 2<sup>™</sup> system can operate as a stand-alone unit or controlled remotely via ANSI E1.11 USITT DMX512-A through the power supply. Refer to the user manual for full details.

Control Menu is accessed via the LCD display and the following controls:

Right hand button (Arrow) - Enter (hold for 2 seconds to save)

Left hand button (Exit) - Exit without saving

Centre pressure slide pad - Adjusts or scrolls through the menu items

To access Control Menu items,

- 1. Use the slide pad to scroll through the menu items
- 2. Press Enter to select the menu item
- 3. Use the slide pad to scroll through the options
- 4. Press Enter for 2 seconds to save the settings

Function

		Function				
Home		Shows the Name, Software Version, current DMX address, control mode and time.				
Control N	Control Mode		PS02/PS06/PS18 Power Supply Units – Software Version 1.6			
Mode	Name	Ch	Grouping	Description		
1	fxHSI	13/25/61	Variable	7 x effects + 2/6/18 x Hue, Saturation, Intensity		
2	HSI	6/18/54	Single	2/6/18 x Hue, Saturation, Intensity		
3	RGB	6/18/54	Single	2/6/18 x Red, Green, Blue (w/ *Magic Amber)		
4	fxHSI	9	All	6 x effects + Hue, Saturation, Intensity		
5	HSI	3	All	1 x Hue, Saturation, Intensity		
6	RGB	3	All	1 x Red, Green, Blue (w/ *Magic Amber)		
7	RGBA	8/24/72	Single	2/6/18 x Red, Green, Blue, Amber		
8	RGBI	8/24/72	Single	2/6/18 x Red, Green, Blue, Intensity		
9	RGBA	4	All	1 x Red, Green, Blue, Amber		
10	RGBI	4	All	1 x Red, Green, Blue, Intensity		
11	LkSel	1	Variable	Selection of pre-programmed looks		
12	DEMO			Stand-alone effects sequence		
*Magic Amber is the term used for the unit's ability to bring in Amber when mixing colors that require it.						
When DMX is Lost In t		In this mode, various options can be selected when DMX is not detected.				
Look Sto	re	In this mode, 42 internal FX Looks are available for stand-alone operation, 1-9 are				
			preset. Looks can be recorded to the internal flash memory and will be reserved on			
		power down. Looks will be returned to default upon reset. To record a Look with a				
		DMX console – set the PSU to Control Mode 1, use the DMX console to create the				
		desired effect, scroll to Look Store number and save the Look to that number. Refer				
		to the Color Span 2 <sup>TM</sup> User Manual to record a Look in Standalone mode.				
and the Loo		Select Time Triggers from the menu, then toggle between Day, Hour (24), Minutes				
		to be triggered.				
Set Day a	nd Time	Select Set Day and Time from the menu then toggle between Day, Hour (24), Minutes				
Display Backlight S		Select Displ. Backlight from the menu then toggle between On (permanently) or Off				
		(after 5 seconds)				
Reset to Default Press Enter for 2 seconds to reset all menu items						
		address=001, Control Mode=1, DMX Lost=Hold, Look Store=default, Time				
			Triggers=deleted, Display=On, Frequency=600			
Frequency		In this mode, four frequency settings are available - 360, 600, 1200, 2400, which				
-		allows for the LED scan rate to be synchronized with the video camera and avoid a				

## 5. Further Information

flickering effect.

Please refer to the Chroma-Q<sup>®</sup> Color Span 2<sup>TM</sup> manual for more detailed information. A copy of the manual can be found at the Chroma-Q<sup>®</sup> website – www.chroma-q.com/support/downloads

## Approvals & Disclaimer



The information contained herein is offered in good faith and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information should not be used in substitution for customer's tests to ensure that Chroma-Q® products are safe, effective, and fully satisfactory for the intended end use. Suggestions of use shall not be taken as inducements to infringe any patent. Chroma-Q® sole warranty is that the product will meet the Chroma-Q® sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted.

Chroma-Q<sup>®</sup> reserves the right to change or make alteration to devices and their functionality without notice due to on-going research and development.

The Chroma-Q<sup>®</sup> Color Span 2<sup>™</sup> has been designed specifically for the lighting industry. Regular maintenance should be performed to ensure that the products perform well in the entertainment environment.

If you experience any difficulties with any Chroma-Q® products please contact your selling dealer. If your selling dealer is unable to help, please contact support@chroma-q.com. If the selling dealer is unable to satisfy your servicing needs, please contact the following for full factory service:

Outside North America: Tel: +44 (0)1494 446000 Fax: +44 (0)1494 461024 support@chroma-q.com North America: Tel: +1 416-255-9494 Fax: +1 416-255-3514 support@chroma-q.com

For further information please visit the Chroma-Q® website at www.chroma-q.com.

Chroma-Q® is a trademark, for more information on this visit www.chroma-g.com/trademarks.

The rights and ownership of all trademarks are recognized

